

Phoenix

DESIGNED FOR YOU

Technical Data Sheet

Range:	Shower Trays
Type:	Legs & Panel Sets
Code:	STLP1 STLP3 STLP4 STLP6 STLP7
Version/Date:	v1 04/16

Assembly of the Universal Leg Set & Panel Kit

For the best results and ease of installation, determine the waste position of the tray. Place the tray in the desired position or best location to simplify the installation. The tray can be rotated indexing the waste to the most suitable position. Fit the waste assembly and exit pipe work (following the waste manufacturers instruction and advice) Place the tray face down on a protective surface or packaging. See over the page and check your size and type of product. Align the legs and panel clips to the diagram overleaf which suits your product.

Your tray is supported by a new reinforcement material with the ability to screw into. Secure each leg with 3x (13mm) 1/2" x No.8 round headed screws provided. Drill a small pilot hole in the base of the tray before attempting to screw into the material. Under no circumstances use a power tool. Screw the screws into the base using a manual screwdriver. Under no circumstances use a longer screw for fixing into the base. Adjust the leg so that the overall assembly is a 100mm to suit the panel location and lightly tighten the hexagonal nut. Depending on which leg clip has been supplied, screw the panel clips to the underside of the tray. It is important that the correct screw size is used for this operation. We recommend that the metal clip is fitted so that it overhangs the tray 4mm. The plastic clip should be fitted to suit the panel return depth as this may vary.

Note!

When moving your tray into position do not slide as this can loosen the leg fixings.

In most cases, your plastic panel(s) is supplied over length. Place onto the clips following the contour of the product if applicable. Mark the pane to length at each end and cut accurately to length with a fine toothed saw. Remove the panel. Turn over the tray and adjust the adjustable feet to level the tray. Fit the panel, which is 100mm in height, into its desired location. Check with a spirit level that the tray is correctly levelled and fully tighten the hexagonal nuts on the legs. Scribe a line on the floor where the panel will sit. Fit to the floor behind the scribed line taking account of the panel return lip. Fit several small blocks of wood (not supplied) to ensure the panel remains stable. It is recommended that the legs at the front of the tray are screwed to the floor. Special care should be taken when using power tools and when drilling take care to avoid hidden pipes or electrical cables.



Finishes:

Guarantee/Aftercare: During installation extra care must be taken to avoid damaging the fittings. We provide a guarantee against faulty manufacture or materials (excluding serviceable parts), providing they have been installed, cared for and used in accordance with our instructions and good plumbing practice.

Phoenix Whirlpools Ltd. Scott Lane, Off Bruntcliffe Road, Morley, Leeds LS27 0NQ

Tel: (Sales) +44 (0)113 2012260 Fax: +44 (0)113 2012268 Email: sales@phoenix-uk.co.uk Web: www.phoenix-uk.co.uk

Notes: Drawings may not be to scale. All dimensions in mm unless otherwise stated. Information correct at time of printing but subject to change at any time.