



- Decide on height position of rail/rails vertically on your radiator.
- Ensure that the rail will be centred in the middle of the radiator horizontally.
- Using the holes in the rails as guides, drill a 2mm pilot hole in the rear of the radiator - These models have hollow front panels, no liquids are contained in the panels.
- Screw the self tapping screws (supplied) through the rail holes to secure it to the radiator, ensuring that the screws do not protrude through the front of the panel. Repeat for other holes.
- Ensure screws are tight.
- Hang your towels onto the front of the rail.

Information:

Guarantee/Aftercare: During installation extra care must be taken to avoid damaging the fittings. We provide a guarantee against faulty manufacture or materials (excluding serviceable parts), providing they have been installed, cared for and used in accordance with our instructions and good plumbing practice. All products installed in a commercial environment carry a 12 month guarantee. We cannot be held responsible for the use of incorrect dimensions shown for first fix without the actual products on site. All dimensions stated are nominal and are subject to manufacturing tolerances.

Finishes:



Chrome



Black