






# Phoenix

DESIGNED FOR YOU

## Stainless Steel Radiator Wall Bracket Fitting Guide

For further assistance or missing parts, please contact your supplier/retailer or contact: [customerservices@phoenix-uk.co.uk](mailto:customerservices@phoenix-uk.co.uk)

- 
- (1)**
1. Measure & mark wall for mounting bracket holes (x4). Insert wall plugs (x4) into drilled holes.
- 
- (2)**
2. Insert large screw (x4) through collar (x4) and screw into wall plug (x4), ensuring a secure fitting.
- 
- (3)**
3. Insert bolts (x4) into bracket tube (x4) and screw to mounting plate on radiator using an allen key.
- 
- (4)**
4. Offer radiator up to wall so that brackets tubes (x4) cover collars (x4). Fix together with grub screw (x4). Support radiator in place whilst performing this assembly.
- 
- (5)**
5. Ensure radiator and all parts are secure before unsupporting the radiator. Continue with plumbing of radiator.