## ◆General Information

Please inspect the product immediately upon receipt for transit damage, missing packs/parts or manufacturing fault. Damage reported later cannot be accepted. Please handle the product with care avoiding knocks and shock loading to all sides and edges of the glass.

## Notes: Safety glass can not be re-worked.

Please read these instructions carefully before start of installation.
Special care should be taken when drilling walls to avoid hidden pipes or electrical cables.
Note: This product is heavy and may require two people to install.

## Aftercare instructions

After use, your shower should be cleaned with soap and water. This is particularly important in hard water districts where insoluble lime salts may be deposited and allowed to build up. Cleaners of a gritty or abrasive nature should not be used. Care should be taken to avoid contact with strong chemicals such as organic solvents and strippers.

Please keep these instructions for aftercare and customer service details.



# S08001/S08002/S08003/ S08004/S08005/S08006/ S08007/S08008






8
7
USE PROTECTOR
TUBES TO SLIDE GLASS
INTO WALL PROFILE
9
2 1 3 6 5 4

1

X1

2



X5

3



ST3.9X35

X5

4



X1

5



X3

6

ST3.5X10

X3

7



X1

8



X2

9



PROTECTOR TUBE X2




Ø6mm


1
X1
2
X4
3
ST3.9X35
X4


a
1
Ø6mm


a
a
a
a


2


3


Ø2.8mm




4
X1


5
X3


6
ST3.5X10
X3


9
X2


9


b
4




b
b
b




Ø2.8mm


5


5
6


Ø6mm


2.5mm
3mm
4mm


2
X1
3
ST3.9X35
X1
7
X1
8
X2


7
Ø6mm
2


Left Side


8
3mm
3
4mm
2.5mm


Ø6mm
2.5mm
3mm
4mm


2
X1
3
ST3.9X35
X1
7
X1
8
X2


7
Ø6mm
2
3
3mm
8
4mm
2.5mm
Right Side



24h